

Amie Pendant

The Amie pendant is a discreet personal activator. Its attractive design and choice of fastening options make it a pleasure to wear.

It comes complete with a neck cord and a clothing clip which will clip to any type or thickness of material. It may also be worn with an optional wrist strap.

An easy press adaptor is also available to enable people with extremely limited dexterity to call more easily.



Features

- Attractive and discreet
- Ergonomically styled with smooth, gloss finish
- Activation light provides clear confirmation of button press and indication of low battery
- Water resistant design - IP67 can be submerged for up to 30 minutes
- 4 Hour automatic transmission of status reports for pendant supervision
- Range of easy wearing options; neck cord, wrist strap, clothing clip
- Easy to keep clean

Technical Details

Part Number	P63604/01 supplied in a box with neck cord and clothing clip
Radio Frequency	312.000 MHz
Battery	<ul style="list-style-type: none"> • Integral battery (not user replaceable) • Typical life 5 years from or 20 activations per day • When the battery is nearing the end of its life, the light flashes when the button is pressed and the call recipient is automatically notified of the low battery state. Battery status is also reported automatically during the 4 hourly supervision transmissions.
Dimensions	1.22"W x 2.29"H x 0.63"D (31 x 58 x 16mm)
Weight	0.04 lbs (20g)
Operating Temp Range	14 F to 131 F (-10 x to +55 C)
Radio Range	390 ft (120m) in free space
Supervision	Full
Standards	FCC CFR47 part 15, Canadian RSS210
Product Compatibility	Caresse+ and Vi+
Optional Accessories	<p>Wrist strap part number D6702021A</p> <p>Replacement neck cord part number D6702063C</p> <p>Easy press adaptor part number 64900/15A</p>

Tunstall Canada Inc.
111 Zenway Blvd, Unit 6A
Woodbridge, Ontario
Canada L4H 3H9

Tel: 1-800-892-2205
Tel: 905-677-1144
Email: info.canada@tunstall.com
canada.tunstall.com
americas.tunstall.com